

Barstool installation instruction



Step 1:Place two barstool legs as in the picture.



Step 2:Slide the 1st ring on over the barstool legs, bolt it together.



Step 3:Slide 2nd small ring inside the two legs and screw it together.



Step 4:Position the swivel plate on the top of the two barstool legs.



Step 5:Screw the 2-ring seat base on the top of the swivel plate.



Step 6:Turn the whole barstool over, screw the 3-ring seat base to the seat pad.



Step 7:Slide the backrest into the tubes, then bolt it.



Step 8:Please insert the rubber caps to the bottom of barstool legs.



Step 9:Please enjoy your EDGE barstool.